

# Table of Contents

<b>Section 1 Introduction</b> .....	<b>1-4</b>
Warranty and Documentation .....	1-4
Release Details.....	1-4
Trademarks and Patents.....	1-5
<b>Section 2 Global Support</b> .....	<b>2-1</b>
Manufacturing Facilities .....	2-1
Regional Offices.....	2-1
International Representatives.....	2-2
<b>Section 3 Safety</b> .....	<b>3-1</b>
Safety and Handling .....	3-1
Operating the Mold .....	3-1
Notices.....	3-1
Cautions.....	3-2
Heater Element Caution .....	3-2
<b>Section 4 Preparation</b> .....	<b>4-1</b>
Screw Lengths .....	4-1
Tools Required .....	4-2
Unpacking .....	4-3
Cleaning.....	4-3
Establishing Your System Type .....	4-3
System with cast in heater element.....	4-4
System with Hydraulic or Pneumatic units .....	4-5
System with Bridged Hydraulic Pneumatic System .....	4-6
<b>Section 5 Assembly</b> .....	<b>5-1</b>
Gate Seal Finishing.....	5-1
Hot Valve / Hot Sprue / FType .....	5-1
Water Cooled Gate Insert Installation (Option) .....	5-2
Thermocouple Installation .....	5-2
Master Series Thermocouple Installation .....	5-2
Thermocouple Removal.....	5-2
Dura Series Thermocouple Installation.....	5-3
This page only applies to legacy Dura nozzles. ....	5-3
Nozzle Insertion .....	5-4
Nozzle Wire Layout.....	5-4
Back Mounted Thermocouples .....	5-4
Front Mounted Thermocouples .....	5-4
Valve Bushings.....	5-5
Types of Valve Bushings.....	5-5
Valve Bushing Installation.....	5-5
Mounting the Manifold .....	5-6
Manifold Locator.....	5-6
Dowel Pin Locator.....	5-6
Manifold and Slot Locator .....	5-7

<b>Section 5 Assembly...cont'd</b>	
Installing the Manifold Thermocouple .....	5-7
Installing the Pressure Disk / Valve Disk.....	5-8
Pressure Disk.....	5-8
Valve Disk .....	5-8
Alternate Method - Air gap adjustment from top clamp or hydraulic plate .....	5-9
Installing Heater Plates.....	5-9
Installation of Inlet Components .....	5-10
Back Plate Installation .....	5-10
Center Heater Installation .....	5-11
Three Piece Center Heater Installation.....	5-11
Inlet Extension Installation.....	5-12
Inlet Extension With Pressure Sleeve.....	5-12
<b>Section 6 Electrical Testing .....</b>	<b>6-1</b>
Wiring Check.....	6-1
Ground Shorts Test .....	6-1
Thermocouple Continuity Test.....	6-2
Pinch Point Test .....	6-2
Heater Continuity.....	6-2
<b>Section 7 Hot Half Assembly .....</b>	<b>7-1</b>
Assembling the Hot Half .....	7-1
<b>Section 8 System Start Up &amp; Shut Down .....</b>	<b>8-1</b>
Start-up.....	8-1
Pre-Start-up .....	8-1
Shut Down .....	8-2
<b>Section 9 Color Change .....</b>	<b>9-1</b>
Color Change .....	9-1
Color Change for a Hot Tip / Sprue System .....	9-1
Color Change for a Valve Gate System .....	9-2
<b>Section 10 Valve Actuator .....</b>	<b>10-1</b>
Installation and Assembly of the Valve Actuator.....	10-1
Pre-Installation .....	10-2
Cylinder Bottom Assembly .....	10-2
Piston Assembly .....	10-2
5500 Only .....	10-2
6X00 and 7100 Series.....	10-2
Cylinder Top Assembly .....	10-3
Valve Pin Finishing of Tip .....	10-3
5500 Series.....	10-3
6X00 Series .....	10-4
7100 Series.....	10-4
Valve Pin Lapping Procedure for Tapered Valve Pins .....	10-5
5500 and 6X00 Series.....	10-5

**Section 10 Valve Actuator...cont'd**

Valve Pin Finishing of Head ..... 10-6  
 5500 Series..... 10-6  
 Valve Pin Assembly ..... 10-6  
 5500 Series ..... 10-6  
 6X00 Series ..... 10-7  
 7100 Series ..... 10-7  
 Installing the Valve Actuator to the Hydraulic Plate ..... 10-8  
 Maintenance Procedure ..... 10-9  
 HY5500, HY6X00 and HY7100 Series..... 10-9  
 For Oil Systems:..... 10-9  
 For Pneumatic Systems: ..... 10-9

**Section 11 Maintenance Procedures..... 11-1**

Valve Disk Removal ..... 11-1  
 Terminal End Removal and Installation ..... 11-2  
 Terminal Removal..... 11-2  
 Terminal Installation ..... 11-2  
 Crimping Tool Chart ..... 11-3  
 Heater Plate Power Lead Replacement..... 11-4  
 Removal..... 11-4  
 Installation..... 11-4  
 Gate Seal Maintenance ..... 11-4  
 Reasons for Gate Seal Maintenance ..... 11-4  
 Multi-Cavity Systems ..... 11-4  
 Gate Seal Removal ..... 11-5  
 Gate Seal Replacement ..... 11-5  
 Latching ..... 11-6  
 Latching the Cavity Plate to the Core Half (Cold Half) ..... 11-7  
 Latching the Cavity Plate to the Manifold Plate (Hot Half) ..... 11-9  
 Torque Settings..... 11-10  
 Gate Seal Torque Settings ..... 11-10  
 System Screw Torques ..... 11-10

**Section 12 Troubleshooting ..... 12-1**

Moisture Related Issues ..... 12-2  
 Resin Moisture Contamination..... 12-2  
 Resin Drying Issues ..... 12-2  
 Importance of Pre-Drying Resin ..... 12-2  
 Pre-Molding Precautions..... 12-3  
 History ..... 12-3  
 Material..... 12-3  
 Hardware ..... 12-3  
 Settings..... 12-3  
 Establishing Root Cause ..... 12-4  
 Fault Identification ..... 12-4  
 Defect types, causes and remedies index ..... 12-5  
 Parts Have Dark Specks ..... 12-6

**Section 12 Troubleshooting...cont'd**

Parts Have Blisters and/or Bubbles ..... 12-7  
 Parts Have Flow Marks ..... 12-8  
 Parts Have Burn Marks ..... 12-9  
 Parts are Delaminating ..... 12-10  
 Parts Have Dimensional Irregularities..... 12-11  
 Parts are Discolored..... 12-12  
 Parts contain Flash..... 12-13  
 Parts surface has Jetting ..... 12-14  
 Parts are Pitted ..... 12-15  
 Parts surface is Rough..... 12-16  
 Parts are sticking to cavity..... 12-17  
 Parts are sticking to core ..... 12-18  
 Parts are short ..... 12-19  
 Parts have sinks or voids..... 12-20  
 Parts display splay ..... 12-21  
 Parts are streaked ..... 12-22  
 Parts are stringing ..... 12-23  
 Parts are warped..... 12-24  
 Parts have weld lines..... 12-25  
 Valve Pin is not closing ..... 12-26  
 Material is leaking..... 12-27

**Section 13 Specialty Systems ..... 13-1**

Main Manifolds ..... 13-1  
 Inlet Seal Installation (without step) ..... 13-1  
 Inlet Seal Installation (with step) ..... 13-1  
 TIT Edge Gated System..... 13-2  
 TIT Edge Gate Seals ..... 13-2  
 Removing the Gate Seal..... 13-2  
 Gate Insert Assembly (Optional) ..... 13-2  
 In-Line Accu-Lever Assembly..... 13-3  
 Accu-Lever Body Assembly ..... 13-4  
 Attaching the Pneumatic Unit..... 13-5  
 Maintenance Schedule ..... 13-7  
 PN1600 and PN1620 ..... 13-7

**Index ..... I**